

Hearing Loop information & Instructions

There are two hearing loops installed in the Village Hall, one in the main Hall and one in the upstairs meeting room. **Only one hearing loop should be on and in use at any one time.**

The main hall has a unit mounted on the wall that displays the system is on and functioning and has a remote mic on the wall. There are also 2 x mics with stands stored in the under-seat store in the bar alcove. The 3-pin plug on/off switch is located left side of stage next to electric distribution panel. All items hi-lighted in photo below.



The meeting room has a mic on the ceiling and one mic with stand that is kept in the storeroom. The 3-pin plug power on/off switch is located to next to the right-hand window, as hi-lighted in photo below.



Any user with a hearing aid should turn their hearing aid to the 'T' setting unless the hearing aid is auto sensing.